



Vector Technologies Ltd.



2020 Parts Catalog





To Order Call: 1 414 247-7100

Spare Parts list 616/624

Qty. Part Description Part Number

37 Complete Set Filter bags (40") 5005-00 *

5 Filter Cages (40") 5010-A0

1 Magnehelic gauge 5040-00

1 Micro Filter Cartridge 5300-00

1 Vacuum gauge 6063-00

1 In-Line filter 5041-00

2 Sets Blower drive belts *

1 Removable Wear Plate 5087-BC

2 Diaphragm Valve, baghouse 5031-02

2 Solenoid Valve, baghouse 5025-00

2 Engine Fuel filter *

2 Engine air cleaner elements-primary *

2 Engine air cleaner elements-secondary *

2 Engine Oil filter *

1 Idler bushing 6720-I1 *

1 Hydraulic oil filter 3011-00

1 Pair, butterfly springs 9136-00

1 Baghouse Timer Board 2033-00D

1 Dump Timer, Repeat Cycle 2314-50

**Spare Parts list 721**

Qty. Part Description Part Number

37 Complete Set Filter bags (40") 5005-00 *

5 Filter Cages (40") 5010-A0

1 Magnahelic gauge 5040-00

1 Micro Filter Cartridge 5300-00

1 Vacuum gauge 6063-00

1 In-Line filter 5041-00

1 Omega Coupling 6174-00

1 Removable Wear Plate 5087-BC

2 Diaphragm Valve, baghouse 5031-02

2 Solenoid Valve, baghouse 5025-00

2 Engine Fuel filter *

2 Engine air cleaner elements-primary *

2 Engine air cleaner elements-secondary *

2 Engine Oil filter *

1 Hydraulic oil filter 3011-00

1 Pair, butterfly springs 9136-00

1 Baghouse Timer Board 2033-00D

1 Dump Timer, Repeat Cycle 2314-50

1 Dryer desiccant kit 4159-01 *



To Order Call: 1 414 247-7100

Spare Parts list for the 6100

Qty Part Description Part Number

37 Complete Set Filter bags (40") 5005-00 *

5 Filter Cages 5010-A0

1 Magnahelic gauge 5040-00

1 Micro Filter Cartridge RC122P *

1 Vacuum gauge 6063-00

1 In-Line filter 5041-00

1 Removable Wear Plate 5087-BC

2 Diaphragm Valve, baghouse 5031-02

2 Solenoid Valve, baghouse 5025-00

2 Engine Fuel filter *

2 Engine air cleaner elements-primary *

2 Engine air cleaner elements-secondary *

2 Engine Oil filter *


1 Hydraulic oil filter 3011-00

1 Pair, butterfly springs 9136-00


1 Baghouse Timer Board 2033-00D

1 Dump Timer, Repeat Cycle

1 Dryer desiccant kit 4159-01 *



2031 CC Pulse System
Wiring



2033 00D Baghouse Pulse
System Circuit Board



2052 01 Round 6 Plug
2052 02 RV 7 Plug




2066 00 Coiled Cable 6
wire
2066 07 Coiled Cable 7
wire




2086 00
10 Amp Circuit Breaker
2086 15
15 Amp Circuit Breaker
2086 20
20 Amp Circuit Breaker
2086 30
30 Amp Circuit Breaker




To Order Call: 1 414 247-7100



2212 10
Push Pull Button
E Stop



2212 20
Push Pull Button
Discharge



2213 10
2 Position Switch



2213 11
NO Contact Block




2213 12
NC Contact Block




2215 00
Limit Switch,
Plunger Actuator



To Order Call: 1 414 247-7100




2314 50
Vacuum/Dump Timer



2291 00 Relay
2294 00 Relay



2310 00
Timer 100K Asbestos



2310 AA
Potentiometer Assembly



2377 AA Warning Light



2379 AB
Emergency Remote
Shutdown Box

Call to order: 1 414 247-7100



2379 AB1 Emergency Remote
Shutdown Interconnect Cord



2643 00
Static Discharge Cable Reel



3011 00
Hydraulic Filter



3010 01 Hydraulic Gauge



3010 00
Hydraulic Housing

Call to order: 1 414 247-7100



2638 00

Toggle Switch SPST

2107 50

Toggle Switch Boot



3125 01 Hydraulic Pump

VecLoader



4039 00 Air cylinder
Spartan 10" Stroke

4040 00 Butterfly Cylinder

4044 AA Air Cylinder
Throttle



4061 00 Air Valve,

Vibrator




4065 00 Butterfly Solenoid

Call to order: 1 414 247-7100



4065 01
Din Connector for the 4065-00



4065 02
Solenoid Valve Throttle



4065 03
1/2 Conduit for 4065-02



4066 00 Air Switch



4068 00
Coiled Air Hose Baghouse

Call to order: 1 414 247-7100



4086 AO Baghouse Vibrator



4097 00

4 way 12VDC 2 Position Air Valve



4097 02 Coil Conduit 120 volt

4097 04 Coil Conduit 12 volt




4098 00 Air Regulator 1/8 port

4142 AO Regulator 1" port




4101 00 Air Pressure Gauge

Call to order: 1 414 247-7100



4110 AO
Compressor Rebuilt
4110 AO1
Compressor New
(early models)



4110 50
Compressor Gasket Kit



4110 AO3
Compressor Front Gasket



4111 AO
Air Governor



4112 AO
Midland Air Dryer


Call to order: 1 414 247-7100



4112 01
Air Dryer Repair Kit (Midland)



4112 02
Air Dryer Purge Kit



4112 03
Air Dryer Heater Element
(Midland)



4112 04
Safety Valve (Midland dryer)



4130 00
Air Valve (3 position manual)

Call to order: 1 414 247-7100



4131 00
Pneumatic Actuator



4154 00 for Air Dryer
for Haldex / Bendix
4159 00 Air dryer
for Holset & Cummins



4159 01
Air dryer Desiccant Kit (Haldex)




4159 06
Safety Relief Valve (170 PSI)




4163 00
Alcohol Deicer Dispenser

Call to order: 1 414 247-7100



Filter Bags w/Cuffs

- 5002 00 4.5" x 40" Nomex
- 5004 AO 4.5" x 28" Filter (coated)
- 5004 AO1 4.5" x 28" w/Ground Wire Coated
- 5005 00 4.5" x 40" Filter Coated
- 5005 01 4.5" x 40" w/Ground Wire Coated
- 5005 12 4.5" x 60" Filter



- 5008 AO 4.5" x 28" Stainless Steel
- 5009 AO 4.5" x 28" Zinc Plated
- 5009 CP 4.5" x 28" Galvanized
- 5009 SS 4.5" x 28" Stainless
- 5010 AO 4.5" x 40" Zinc Plated
- 5010 CP 4.5" x 40" Galvanized (S.R.N.)
- 5011 00 4.5" x 40" Stainless Steel
- 5013 00 4.5" x 60" Zinc Plated



Filter Bags w/Snap Neck Ring

- 5004 CP 4.5" x 28" Filter Coated (S.R.N)
- 5006 00 4.5" x 40" Filter Coated (S.R.N)
- 5006 01 4.5 X 40" Filter Coated (S.R.N) Grd.
- 5006 02 4.5" x 40" Filter (Raton) (S.R.N)
- 5006 38 4.5" x 38" Filter Coated 38" (S.R.N)

Call to order: 1 414 247-7100



5025 00
Solenoid Baghouse



5031 01 Pre-06/2016
4 Bolt Diaphragm Kit



5031 02 Diaphragm Valve 3/4"



5031 03
06/2016 Diaphragm Repair Kit



5058 CC1
Complete Standard Dump
Door Assembly

Call to order: 1 414 247-7100




5033 00

Differential Pressure (0-10)


5040 00

Differential Pressure (0-50)



5041 00

Filter in-line 40 micron for Mag
gauges



5049 AA

Gasket, Dump Door



5067 BE Air Horn Poly



5081 BC Removable Wear Plate
9.5" Liner

5087 BC Removable Wear Plate
11" Liner

5516 BC Removable Wear Plate
for 44" Baghouse


5516 BC1 44" Baghouse
9.5 " liner

Call to order: 1 414 247-7100



5098 CC

Air Manifold Weldment 8"
w/Nipples



5150 00

Hepa filter



9653 00

Hepa Filter for the vent assy.



9653 01

Hepa Cartridge


Call to order: 1 414 247-7100



5152 A0
Filter 22" bottom Load

5153 00 Filter 26"

5300 00 Filter 36"



5159 00 Hepa Filter 12.75"x 22"

5159 50 Hepa Filter 17.75"x 24"



RC122P
Secondary Filter Cartridge
6100-HP 2 Required



A5551 CC
Inlet Pipe Removable 8"

5164 BC
Inlet Pipe Removable 6"

5172 BC
Inlet Pipe Removable 5"

Call to order: 1 414 247-7100



5066 BE 11" Wear Plate
5079 BE 9.5" Wear Plate
9215 00 Plow Bolts
9215 01 Sealed Washers 3/8"



5175 AE
Upper Auger Wiper Retainer
5176 AE
Wiper Auger Paddle



5177 AE
Wiper Retainer Bar




3016 00 Auger Motor 44" & 54"
3060 00 Hyd. Hose 3/8 x 27 1/2"
5185 BE Flange For Upper Auger Shaft
5186 AO Hydraulic Motor Adapter
A5188 CC Upper Auger 44" Asbestos
5188 CC Upper Auger 54" Asbestos
5191 CC Lower Auger 44" & 54"
9321 00 Sleeve Bearing 44" & 54"

Call to order: 1 414 247-7100



5121 CC
Cone 72" x 12" 45*
5178 CC
Cone 54" 17" OD Flange
5178 CC-SS
Cone 54" Stainless Steel



5204 00
Filter Cartridge w/inner wire

Call to order: 1 414 247-7100



5313 AC
Pinion Gear Hepa Slide Gate



5320 AE
Gasket Slide Gate to Cone



5321 00
Seal w/O-Ring Slide Gate



5322 00
O-ring Slide Gate



5333 AE
Valve Plate Roller Slide Gate

Call to order: 1 414 247-7100



5342 BE Roller Shaft Slide Gate



5380 00 Flat Washer 5/16"
brass



5381 00 Cotter Pin 1/16" X 3/4"



5404 01 16" Manway Gasket
5405 01 20" Manway Gasket



5404 A2 16" Retaining Ring
5405 03 20" Retaining Ring



5405 02 Cam Assy. 16" & 20"

Call to order: 1 414 247-7100



A5127 DC 72" Removable
Flange Wear Section

5506 DC 54" Removable
Flange Wear Section



6005 00 Ignition Switch

6005 01 Key Set John Deere



6010 00 Throttle Cable 72"

6011 AE Throttle Cable 36"

6011 AE1 Throttle Cable 48"

6320 00 Throttle Cable 30"

6660 01 Thr cable (PE6068T)



6004 00 Tach (up SN 141)

6017 00 Tach

6043 00 Tach w/hour meter

6043 02 Tach w/o hr. meter

6097 00 Tach

6653 06 Tach w/hr. meter

Call to order: 1 414 247-7100



6055 00 Amp Meter 0-60



6055 01 Volt Meter 616HP



6057 00 Temp Gauge w/8" TB

6057 01 Temp Gauge 616 HP

6058 05 Temp Gauge



6057 02 Temp Sender 616HP

6058 06 Temp Sender



6058 00 Oil Pressure Gauge

6058 01 Oil PSI gauge 616HP

6058 03 Oil Pressure Gauge

6059 00 Oil PSI Murphy

Call to order: 1 414 247-7100




6058 02 Oil Sender Tier 1



6060 00
Safety Switch Murphy



6061 00 Hour Meter



6063 00 Vacuum Gauge
Glycerin Filled



6052 00 Tach Cable 36"
6064 00 Tach Cable 40"
6065 00 Tach Cable 72"
6066 00 Tach Cable 21-
5/16"

Call to order: 1 414 247-7100



6113 02 616DVJ 3/4 Plug Vent
6113 21 616 DVJ 1/2" Plug Vent
6248 02 721 Breather Cap (21)



6113 37 Sight glass 3/4" NPT
6121 00 Sight glass 418 1/2 NPT



6174 00 Omega Element E60
6180 00 Omega Element E4
6180 05 Omega Element E5
6186 AO Omega element E20
6193 AO Omega element E30
6510 00 Omega element E70



6208 01 Fuel Gauge Electric



6208 03 Fuel Gauge Sender

Call to order: 1 414 247-7100



6467 03 Pop up w/stem



6467 04 Pop up Gasket



6467 08 Electronic Control Valve



6633 03 Falk Element
6633 01 Falk Assembly



6653 02T7 Compressor
6068HF275 225 Hp. T2

Call to order: 1 414 247-7100



6660 02T10 Diesel Eng.
Powerview



6660 02T11 Diesel Eng.
Powerview Rocker



6660 02T16
Key John Deere Engine Enclosure



6660 02T18 Rocker Switch
Rabbit5/Turtle
6660 02T18M Rocker Switch
Rabbit/Turtle Momentary



6679 03T05 Electronic Throttle
Control



6695 03T12 Fan Control
Engine Cooling 6.8L Teir3

Call to order: 1 414 247-7100



6720 I1 Bushing IDQ1 x 1"
Browning

6723 S6 Bushing SFBB x 3/4"
Idler

6723 S7 Bushing SKBB Idler

6723 S9 Bushing SF-BB 1"



6725 03T14 Vac Valve Air
Cleaner Cover



6727 03T1 Lock cylinder w/
Keys Eng. Instrument Panel
Cover



6727 03T11 Lock Cam
Engine Instrument Panel Cover



7022 00 Hose Clamp 4" DB

7023 00 Hose Clamp 5" DB

7024 00 Hose Clamp 6" DB

7025 00 Hose Clamp 8" DB

Call to order: 1 414 247-7100



7025 AE Sleeve 2.5" ST. 6" Long

7026 AE Sleeve 4" ST. 8" Long

7027 AE Sleeve 5" ST. 8" Long

7028 AE Sleeve 6" ST. 9" Long



7025 BC Sleeve 2.5" w/handle 8" Long

7026 BC Sleeve 4" w/handle 8" Long

7027 BC Sleeve 5" w/handle 8" Long

7028 BC Sleeve 6" w/handles 9" Long



7040 DC Roof Nozzle 4"

7050 DD Roof Nozzle 5"

7050 DD-HD Roof Nozzle, 5" H.D. Reinforced



7042 BC Bulk Nozzle 4"

7052 BC Bulk Nozzle 5"

7062 BC Bulk Nozzle 6"

Call to order: 1 414 247-7100



Inlet reducers

7202 AC 5" OD to 4" ID
7202 AC1 6" OD to 5" ID
7202 BC1 6" OD to 5" ID
7202 AC2 8" OD to 6" ID

7207 CE 5"x2.5" Male
7209 AC 6"x 4" QD
7206 AC1 6"x (4) 2" Splitter



Male Wye

7211 AC 5x3x3 OD
7212 AC 4x2x2 OD
7212 AC1 4x4x4 OD
7220 BC1 Wye 8x4x4 OD

Lateral

7226 AC 6"x2.5"
Pipe



Wear Elbow Blasting Style

7235 BC 4" Wear Elbow

7236 BC 5" Wear Elbow

7237 BC 6" Wear Elbow

7237 BCR 6" Wear Elbow
Reinforced

Call to order: 1 414 247-7100



Roofing Style Wear Elbow

7236 BC3 5"

7237 BC3 6"




7259 AC 6" PVC Adaptor



7404 00 4" Hose/PVC Coupling

7406 00 6" Hose/PVC Coupling



7546 00 4" Vacuum Breaker

7556 01 5" Vacuum Breaker

7566 00 6" Vacuum Breaker



7540 00 4" Ring Lock Coupling

7550 00 5" Ring Lock Coupling

7560 00 6" Ring Lock Coupling

Call to order: 1 414 247-7100



7594 AC 4" Hose Guard

7595 AC 5" Hose Guard

7596 AC 6" Hose Guard

7598 AC 8" Hose Guard



8255 00 3-way Diverter Ball Valve 1/2"



8298 00 Fog Jet Nozzle Brass



8299 00 Nozzle Vee Jet Brass

8300 00 Full Jet Nozzle Brass

8302 00 Flood Jet Nozzle

1/4K- 7.5 Brass



9023 00 Spring vacuum relief valve

Call to order: 1 414 247-7100



8307 00 Poly T Strainer 3/4"
8307 01 Strainer Screen Blue
9307 01W Strainer Screen Wht.
8307 02 Bowl/ w Gasket
8307 03 Gasket



8308 200 Poly Y strainer 2"



9019 00 Hand Jack #5,000
9019 AE Hand Jack Mount Tube



9028 00 6" Butterfly Valve Disc
9029 02 4" Butterfly Valve Disc
9117 AO1 5" Butterfly Valve Disc
9135 01 12" Butterfly Valve Disc
9137 00 8" Butterfly Valve Disc


Call to order: 1 414 247-7100



9043 00 Draw bar 3" Eye
9043 30 Draw bar 2.5 " Eye



9045 00 Rubber Wheel Chocks



9047 00 Hydraulic Tank Cap 2"



9048 00 Fuel Cap 2" Locking
9491 00 Fuel Cap 3" Locking
9491 01 Key set, 3" Locking
Cap



9058 00 Lynch Pin

Call to order: 1 414 247-7100



9062 00 Clevis Pin 1/2" x 4"
9063 00 Clevis Pin 1" x 3-1/2"



9066 00 Clevis Sling Hook 3/8"



9080 00 Jack stand Pin Asm.



9374 01 Sight Glass Replacement
9374 02 5" Hand Wheel
9374 03 Gasket
9374 04 Disc plate

Call to order: 1 414 247-7100	
	9087 50 Latch Spring Clip (Lid Lift)
	9933 00 Rod End
	9935 00 Handle 1/2"
	0683 AE Rod Mount, Pop- top
	0685 AE Latch Plate - Flange Inlet
	9088 00 Latch Spring Clip
	9097 20 Toggle Clamp
	9113 50 Latch Assembly Engine Shroud

Call to order: 1 414 247-7100



9113 00 Folding T"
Latch

9113 01 Key for Latch



9113 60 Lock Assembly
Engine Enclosure



9103 01 Fuel gauge
Twin Site Sender



9117 AO Butterfly 5"
9029 00 Butterfly 6"
9134 00 Butterfly 8"
9135 00 Butterfly 12"


Call to order: 1 414 247-7100



9135 02 Replacement Shaft
12" Butterfly



9136 00 Butterfly Spring Set



9173 00 Name Plate



9205 00 5/16"x1/2" SS Shoulder
Bolt



9206 00 Jam Nut 3/4"-10 SS

Call to order: 1 414 247-7100



9215 00 Inner Wear Plate Bolt
3/8"-16x1"



9215 01 Sealed Washer 3/8"x3/4"
9215 02 Sealed Washer 1/4"x1/2"



9215 AC Tower Pin w/Grease Fitting
9215 AE Tower Pin



9300 00 Breakaway Control
Kit
9300 LED Battery Box
9300 LED-1 Battery
9300 03 Breakaway Switch
9300 04 Breakaway Cable



9289 00 License Plate Bracket

Call to order: 1 414 247-7100




9303 01 6K Grease Cap



9307 00 Junction Block 7 pole



9391 00 Grease Cap 7K Hub



9517 AA Baghouse Timer Box
(Old style board)



9517 00 Baghouse Timer Box

Call to order: 1 414 247-7100



**A1055 BC, 9589 60,
& RCCFT-100-12**

Discharge Adapt 12"Standard x 10"ANSI
10" Butterfly Valve Assembly
Comp Fl. Tube 100Dx12"Lg



9533 00 Tool Box

9533 01 Lock & Key Set

9533 AA Tool Box (new style)



A5070 AA

Hazmat Dump Door Assembly



9840 DC

Dual Orifice Gate Assembly



9589 60 10" Butterfly

9590 00 6" Butterfly Assy.

Air To Close Spring To Open

9590 50 6" Butterfly Assy.

Air to Open Spring To Close

Call to order: 1 414 247-7100



9590 AA Drum Filler 4"



9595 AA Drum Filler Std.
9024 00 3 Ring 55 Gallon
Drum



9596 AA Hopper Assy. 1 cu. Yd.
9597 AA Hopper Assy. 2 cu. Yd.
Self dumping




9638 AA Hepa Slide Gate



9912 AA Slide Gate Repair Kit

Call to order: 1 414 247-7100



Clutches

6997 00 * (616/624)

6997 50 * (721)

6998 50 * (6100)

6994 01 Twin Disc 11.5"
Service Kit.




Intermediate Separators

self dumping hoppers

9596 AA 1 Cubic Yard

9597 AA 2 Cubic Yard



B9701 AA 54"

Separator w/Stand

B9701 AA1 54"

Separator Skid




9749 AA Roof

Hopper/Rock Separator

w/ Tow Package

Call to order: 1 414 247-7100



Vacuum Hoses

Heavy Duty AR

7320 TR1X100 2" x 100'

7325 TR1X100 2.5" x 100'

7330 TR1X100 3" x 100'

7340 TR1X50 4" x 50'

7350 TR1X50 5" x 50'

7360 TR1X50 6" x 50'

7380 TR1X50 8" x 50'

Ask about available hose length's

Clear Heavy Duty

7342-00 2"

7343-00 3"

7344-00 4"

7345-00 5"

Urethane lined

7340 U1 4" HD Black Hose

7340 U2 4" Extra HD Blue Hose

7350 U1 5" HD Black Hose

7350 U2 5" Extra HD Blue Hose

7360 U1 6" HD Black Hose

7360 U2 6" Extra HD Blue Hose

7380 U1 8" HD Black Hose

7380 U2 8" Extra HD Blue Hose

Hopper Hose

7360-00: Hopper Hose 6" x 16'

7360 01: Hopper, w/ Ground

6"X16.5'

7363-00: 8" x 16' High temp.

Call to order: 1 414 247-7100

Blank

Table of Contents

Spare parts list	
616/624	Page 2
721	Page 3
6100	Page 4
Electrical	Page 5-8
Hydraulics components	Page 8-9
Pneumatic components	Page 9-14
Bag house filters	Page 15
Dump chute & door	Page 16
Air system components	Page 16-17
Bag house air manifold	Page 18
Hepa filters	Page 18
Micro filters	Page 19
Bag house inlet tube	Page 19
Auger assy.	Page 20
Cone	Page 21
Diaphragm and kit	Page 21
Filter Cartridge	Page 21

Wear plates	Page 21
Hepa slide gate components	Page 22-23
Manhole components	Page 23
Wear section	Page 24
Keys & ignition	Page 24
Throttle cable & Tach	Page 25-26
Amp, volt & oil gauges	Page 25-26
Temp & oil Senders	Page 26
Hr meter	Page 26
Tach cable	Page 27
Blower vent & sight gauge	Page 27
Omega coupling	Page 27
Elect. fuel gauge & sender	Page 28
Posi Seal & gasket	Page 28
Electronic control valve	Page 28
Faulk coupler	Page 28
Air compressor	Page 28
Power view & switch	Page 29

Power view rocker (+/-)	Page 29
Power view rocker (turtle)	Page 29
JD Eng. Enclosure Key	Page 29
Electronic throttle control	Page 29
Fan controller 6.8L tier 3	Page 29
Idle bushing	Page 30
Air cleaner	Page 30
Eng. Instrument panel lock	Page 30
Hose clamps 2 bolt style	Page 30
Hose sleeves	Page 31
Hose sleeves with handle	Page 31
Roof nozzle	Page 31
Bulk nozzle	Page 31
Inlet reducers	Page 32
Reducers	Page 32
Wyes	Page 32
Lateral	Page 32
Wear elbow	Page 33 –33
Hose coupling M/F	Page 33

Hose coupling Male	Page 33
Hose coupling Female	Page 33
Compression clamps	Page 33
Ring lock coupler M/F	Page 34
3– way diverter ball valve	Page 34
Fog jet nozzle brass	Page 34
Nozzles	Page 34
Vacuum relief spring	Page34
Strainer T	Page 35
Hand jack	Page 35
Butterfly disc	Page 35
Drawbar ring	Page 36
Chock	Page 36
Fuel & hydraulic caps	Page 36
Lynch pin	Page 36
Sling hook	Page 37
Jack stand pin	Page 37
Clevis pin	Page 37

Sight glass	Page 37
Latch spring clip (lid)	Page 38
Latch spring clip (cone)	Page 38
Toggle clamp	Page 38
Latch engine shroud	Page 38
Latch folding T	Page 39
Latch engine enclosure	Page 39
Fuel gauge	Page 39
Butterfly valve	Page 39
Butterfly shaft	Page 40
Butterfly springs	Page 40
Name plate	Page 40
Shoulder bolt	Page 40
Tower bolt	Page 41
License plate	Page 41
Plow bolt	Page 41
Sealed washer	Page 41
Tower Bolt with grease fitting	Page 41
Breakaway system	Page 41

Junction Box	Page 42
Grease cap	Page 42
Baghouse timers	Page 42
Wet head pick-up	Page 43
Tool box	Page 43
Wet head power module	Page 43
Double dump	Page 43
Auger part break down	Page 43
Butterfly valves	Page 45
Drum filler/ top hat	Page 44
Drum filler with stand	Page 44
Hopper containers	Page 44
Hepa slide gate	Page 44
Slide gate repair kit	Page 44
Clutches	Page 45
Separators	Page 45
Hoses	Page 46